


2.2.8. Communication with E3DC

When communicating with the E3DC energy management system, it is important that the heat pump and the energy management system are in the same network. Communication between the heat pump and E3DC takes place automatically via the network (E3DC protocol / port 502). The surplus electricity is used for domestic hot water preparation, heat storage and heating management.



i For communication between the iDM heat pump and the E3DC energy management system, the IP address of the E3DC must be set in the navigator control!

i The „E3DC“ (Simple Mode) Modbus TCP protocol must be configured on the E3DC!

„Modbus function“ settings on the E3DC

